

# MONTAGE

- BOOOM 50 BR, heavier than 2 kg -
- Metal Ceiling Plate (Standard) -


1. Attach the bracket (A) to the ceiling. (Mounting screws are not included)
- 2a. Determine the height of the lamp and, if necessary, shorten the electric cable (H). The standard supplied length is 180 cm. A longer cable length is possible upon request.

- 2b. Shorten the electric cable:

- Loosen the screw cap (G) and strain relief (F) from the ceiling plate (E).
- Disconnect the cord at the luster terminal (C).
- Determine the desired length.
- Cut the cord, strip the sheath and then strip the wires to a length of about 8 mm.
- Re-tighten the strain relief (F).

- 2c. Shorten the steel cable:

- Turn point (J) halfway.
- Press in point (J) and push the cable to the correct length.
- Re-tighten point (J).



3. Connect the electricity to the luster terminal (C). Connect each wire that comes from the lamp to the same color wire that comes from the ceiling.
4. Attach the ceiling plate to the bracket with the two screws.
5. Enjoy the light.



# BOOOM!

## GENERAL INFORMATION


- Fitting E27, max. 40 W
- Beware of sharp edges
- Only for indoor use
- Not suitable for wet areas
- Light bulb not included

By Marc de Groot  
Joris van den Berghweg 103 - B 0.03  
1067 HP Amsterdam  
The Netherlands


info@bymarcdegroot.com  
www.bymarcdegroot.com




# COMPONENTS



- (A) Mounting bracket for ceiling (screws not included)
- (B) Two screws
- (C) Luster terminal (not included)
- (D) Nut
- (E) Ceiling plate with steal cable
- (F) Strain relief
- (G) Screw cap
- (H) Eye nut
- (I) Electricity cable and fixture



Always switch off the power before starting the installation.



# MONTAGE